


ELEVATION VIEW

1. CUT PIPE AS REQUIRED TO CENTER FULL JOINT @ SS CROSSING.
2. INSTALL CDF FROM ABOVE COVER MATERIAL TO 6" ABOVE (E) SS FOR FULL WIDTH OF TRENCH & 12" BEYOND EACH WALL OF ORIGINAL SS TRENCH LINE.



SEWER MAIN CROSSING

SCALE: NONE

**LBNL STANDARD
SEWER MAIN CROSSING**

| | |
|----------------|-------|
| DRAWN BY | DATE |
| CHECKED BY | |
| APPROVED BY | |
| CAD FILE PATH | |
| SCALE | NTS |
| DRAWING NO. | SHEET |
| U 1 2 0 | |
| PROJECT NO. | |

UNIVERSITY OF CALIFORNIA LAWRENCE BERKELEY NATIONAL LABORATORY
FACILITIES DIVISION